
Message Waiting Lamps Reset (LD 61)

The Message Waiting Lamps Reset program (LD 61) can be invoked automatically by the system as part of the daily routines or manually from an input device. It is used to deactivate all active Message Waiting lamps on user stations and reset the associated status in the system. Problems are identified in MWL messages.

The program does not reset lamp status unless all message center sets are out-of-service. For instance, the message center is closed and attendants are in Night Service.

This program cannot be applied to digital sets.

When LD 61 is loaded manually, 'G' is entered to initiate the task.

MWL messages

MWL0000	Program has been loaded.
MWL0001	Invalid command. Action: Re-enter the command.
MWL0002	Cannot deactivate MW lamps until all MC agents out-of-service. Action: Take all MC out-of-service if possible.
MWL0003	Cannot deactivate MW lamps until all attendants in Night Service. Action: Take all MC attendants out-of-service. Operate night key.
MWL0500 dn tn	The TN specified has been flagged as having a faulty lamp. The unit status has been set to normal. Action: Check the lamp(s) visually or by using LD 32 PBXT command.